

# SC-100-ASCII-Pelco

## Pelco ASCII to Pelco RS-422 Code Convertor

The code convertor converts Pelco ASCII protocol into Pelco RS-422 code.

ASCII input is 9600 baud Odd parity.

Pelco output can be set to "P" code from 2400 to 19200 baud with even or no parity, or it can be "D" code at 2400 baud with no parity.

A test mode sends a continuous square movement pattern to the P/T so the communications from the translator to the P/T can be checked without an ASCII input. The input receiver is disabled during test mode.



**Test Address Selector**  
Selects the test mode camera address. The valid address range is 001-256

**Rx Indicator**  
Flashes when there is data on the input lines.  
Stays on if the input lines are reversed.

**Error Indicator**  
Flashes on input receive error.

**Status Indicator**  
Lights if an invalid address is selected.

**Tx Indicator**  
Flashes when Pelco output code is sent.

**Configuration Switches**

**Switch 1: Unassigned**

Up:  
Down:

**Switch 2: Pelco Code type**

Up: "P" code  
Down: "D" code

**Switches 3&4: "P" code baud rate**


1 Down	2 Down	2400 baud
1 UP	2 Down	4800 baud
1 Down	2 Up	9600 baud
1 UP	2 Up	19200 baud

**Switch 5: "P" Code Parity**

Up: Even parity  
Down: No parity

**Switch 6: Output test code**

Up: Output test pattern On  
Down: Output test pattern Off



The removable mounting clip can be snapped onto a din rail or screwed to a panel or wall.

Rx Com  
Data  
Input    Power    Data  
                                 Output

Connect power wires to the PWR inputs. Do not connect power wires to the Gnd.

**Removable edge connector**  
Insert a small screwdriver in the upper slot to force open the wire clamp. Push in all the way to open fully. Place stripped wire end(s) in the open clamp and withdraw screwdriver.

### SPECIFICATIONS

Size: 4.5" x 3.5" x 1.25"  
 Weight: 0.5 lb  
 Power: 9~15Volt AC or DC at 75ma (24Volt optional)  
 Environmental: Indoor use only

[www.sennetech.net](http://www.sennetech.net)

Sennetech, Inc. 6455 W. Bath Rd. Perry, MI 48872 U.S.A. Tel (517) 675-1150 Fax (517) 675-1151

## NOTES

### **Switch Settings**

Any changes in switch settings are effective immediately, they are not read only on power up.

### **Addressing**

Upon power up and during test mode, the camera address is set by the Test Address Selector Switches. This address will be used until an ASCII input is received with new address information.

### **Indicators**

The **Rx** LED will flash when there is data on the input.

The **Error** LED will flash on input receive errors, ie wrong baud rates, etc

The **Status** LED will light will glow dimmly if the selected test address is not in the valid range of 001 to 256

The **Tx** LED will flash for each Pelco packet sent.

## OPERATION

### **PTZ**

Pelco ASCII pan, tilt, zoom, focus, and iris commands into equivalent Pelco RS-422 commands

Also supported are program preset, goto preset, record pattern, end pattern recording, run pattern, Aux On, and Aux Off